

```

BLMTfil = {
    exec "samtools view -b -L hg19whitelist.bed -q 10 -o $output.bam $input.sam"
}

sort = {
    exec "samtools sort -o $output.bam $input.bam"
}

rmdup = {
    exec "MarkDuplicates.sh I=$input.bam O=$output.bam M=$output.txt REMOVE_DUPLICATES=true
    VALIDATION_STRINGENCY=SILENT"
}

csort = {
    exec "samtools sort -o $output.bam $input.bam"
}

index = {
    exec "samtools index $input.bam"
}

tdf = {
    exec "igvtools count $input.bam $output mm10"
}

nsort = {
    exec "samtools sort -n -o $output.bam $input.bam"
}

bed = {
    exec "bedtools bamtobed -bedpe -i $input.bam > $output"
}

peaks = {
    exec "macs2 callpeak -t $input.bam --nomodel --nolambda --keep-dup all -f BAMPE -g hs -
    n $input.bam"
}

Bpipe.run {
    trim + align + BLMTfil + sort + rmdup + [index + tdf, peaks]
}

```

**-b** Output in the BAM format.

**-L FILE** Only output alignments overlapping the input BED FILE [null]

**-q INT** Skip alignments with MAPQ smaller than INT [0].

**-o FILE** Output to FILE [stdout]

**-n** Sort by read names (i.e., the **QNAME** field) rather than by chromosomal coordinates.

**Bamtobed** converting bam files to bed file for input for MACS2

## MACS2:

Fundamental commands

**callpeak** call the peaks in the data

**nomodel** no shifting model of peaks used (used for ChipSeq data not required for ATAC-seq)

**nolambda** by default MACS uses local noise `-backgrnd` reads to call peaks

**keep-dup all** if a set parameter is defined MACS will ignore read counts that exceed the specified parameter.

